


合格证
QC PASS

Godox



Wechat
Official Account
神牛微信公众号

深圳市神牛摄影器材有限公司

地址: 深圳市宝安区福海街道塘尾社区福川工业区厂房2栋 电话: 0755-29609320(8062)

传真: 0755-25723423 邮箱: godox@godox.com

GODOX Photo Equipment Co.,Ltd.

Add.: Building 2, Yaochuan Industrial Zone, Tangwei Community, Fuhai Street, Bao'an District,

Shenzhen 518103, China Tel: +86-755-29609320(8062) Fax: +86-755-25723423

E-mail: godox@godox.com

godox.com

Made in China | 705-F600BY-00



KNOWLED F600 Bi

柔性LED灯
KNOWLED Flexible LED Light

使用手册
Instruction Manual

规格参数

型号	F600Bi
供电	100V~240V-50/60Hz 6.7A
输入功率	≈670W
色温	2700-8500K
调光范围	0%-100%
调光类型	线性/S型/指数/对数
FX场景光效	11类
CRI	平均≥96
TLCI	平均≥96
灯体防水等级	IP65
控制方式	DMX 512控制台控制, 支持RDM协议/2.4无线控制/蓝牙APP控制
蓝牙控制距离	≈30m
2.4G控制距离	≈60m
Type-A USB接口	固件升级/5V 1A供电
尺寸	灯体: 1210mm*1210mm*24mm(不包含连接线) 控制器: 179mm*123mm*332mm
净重 ^①	灯体: 3.8kg 控制器: 3.9kg

设计和规格如有变更, 恕不另行通知。

本设备包含型号核准代码为:CMIITID:2020DP13510, 为该产品的无线电发射模块。

Safety Instructions and Attentions

First of all, as the most basic principle: This product is a professional lighting set equipment and should be used by professional lighting engineers or under the guidance of professionals. Basic safety attentions must always be followed during use, as follows:

1. Before use, please read and understand these instructions and attentions.
2. Professional lighting is prohibited for children. When children are near, parents or accompanying persons must supervise closely to prevent children from personal injury due to collision with lamps or private use of lamps.
3. This lighting product is not ordinary lighting product and cannot be used for general lighting. Anyone who has suffered eye damage or has sensitive eyes should avoid using this product.
4. When the lamp is on, it must be used with care. Do not touch high-temperature parts, such as LED lamp beads, to avoid burns.
5. When the lamp is on, it is forbidden to look directly at the lamp beads under any circumstances. Strong light should be used under the guidance of professional lighting engineers. Avoid prolonged exposure to strong light under any circumstances. If eye discomfort, please turn off the lamp in time, suspend use, and see a doctor immediately.
6. If the lamp bead is damaged or deformed by heat, stop using this equipment, and contact the manufacturer, service agent or qualified maintenance personnel to replace the lamp bead in time to avoid accidents.
7. This product is only suitable for use in -20°C to 40°C operating environment and normal humidity environment.
8. Do not use damaged equipment or accessories, and wait for professional maintenance personnel to check and repair to confirm being normal before use.
9. During using, if the casing of this product is broken due to being dropped, squeezed or subjected to strong impact, please do not use it, so as to avoid electric shock injury due to contact with internal electronic components.
10. If an extension cord is required, please use an extension cord with a current rating greater than or equal to that of the equipment. If an extension cord is rated less than the equipment, overheating may result.
11. Some products have long power cords, please place the power cords properly and keep them in a safe place. Avoid contacting the power cord with overheating surfaces, avoid improper placement that could cause pulling damage, or trip on-site personnel. Please use the certified power cord from the original manufacturer. If the product is damaged by using a non-certified power cord, it will not be repaired by our factory.
12. Be sure to unplug equipment from the power outlet before cleaning and repairing. When not in use, do not pull the power cord to unplug the equipment. For normal power-off, please hold both ends of the plug of the equipment with your hands and pull the plug out of power outlet. This equipment needs to be connected to a grounded outlet.
13. Do not disassemble the product without permission. If the product fails, it must be checked and repaired by authorized maintenance personnel.

14. Before storing, make sure that the equipment has cooled down completely. For storage, unplug the power cord from the equipment. The equipment should be placed in the carrying case or in a ventilated dry place.
15. Do not place equipment near flammable and volatile solvents such as alcohol and gasoline.
16. Do not use accessories that are not recommended by our factory to avoid fire, electric shock or personal injury.
17. When cleaning, do not wipe it with a damp cloth, please use a dry cloth or a soft cloth to wipe the dirt of the equipment.
18. Please take off the protective cover before using.
19. This product complies with ROHS, CE and FCC certification, please refer to the relevant national standards for use and operation.
20. The safety instructions are formulated according to the strict testing of the factory, and the design and specifications of the equipment are subject to change without prior notice. For latest product information, please check the GODOX website and view latest electronic instruction.
21. Some products have built-in lithium batteries. Please use specified chargers, and use them within a proper range of the specified voltage and temperature according to the correct operating instructions.
22. Some products are battery powered. Do not use any batteries, power sources or accessories not specified in the instructions for such products. Keep batteries and other accessories out of the reach of children and infants. In the instance that a child or infant swallows a battery or accessory, immediate emergency medical attention is required. If the battery leaks, becomes discolored, deformed, emits smoke, or emits an abnormal odor, remove it immediately. Be careful during removal to avoid burns. Continued use could result in fire, electric shock, or burns. Do not use any deformed or modified batteries. Do not disassemble or modify this product or battery. Do not heat or solder the battery. Keep the battery away from fire or water. Do not incorrectly insert the positive and negative ends of batteries, or mix old and new batteries or batteries of different types together.
23. One-year warranty period, accessories such as consumable batteries, adapters, power cords, etc. are not covered by this warranty.
24. If it is found that the equipment is repaired without authorization, the one-year warranty period will be cancelled and relevant fees will be charged for maintenance.
25. Machine failures caused by non-standard operation are not covered by the warranty.

keep these instructions!

Foreword

Thank you for purchasing!

Introducing the new and waterproof KNOWLED Flexible LED Light from Godox - F600Bi. Compatible with 110V-240V power supply, this light can be used anywhere in the world. F600Bi is packed full of functionalities, which include controller power supply, stepless brightness adjustment, IP65 waterproof & dust-proof light body, 4 dimming curves, cold and warm color temperature, multiple wireless controlling methods and more. This makes it suitable for short video shooting, advertising shooting, e-commerce live streaming, commercial photography, film & TV shooting and etc.

Main Features


- Wide CCT range adjustable from 2700K to 8500K.
- Four dimming curves: linear, s-curve, exponential, logarithmic.
- Stepless brightness adjustment from 0% to 100%.
- Various Controlling methods: DMX 512 controller/Bluetooth APP control/2.4GHz remote control.
- IP65 waterproof & dustproof rating of the light body
- 11 FX modes: flash, lightning, cloudy, broken bulb, TV, candle, fire, firework, explosion, welding, SOS.

▲Warning


- ▲ Do not look directly at the LED light or illuminate at others' eyes.
- ▲ Do not plug or unplug the power cable or connecting cable when the power is turned on, otherwise personal injuries may occur.
- ▲ Do not cover the heat dissipation vent in working status.
- ▲ Keep out of reach of children.
- ▲ Please make sure to follow the instruction manual and correctly use this professional lighting device.
- ▲ Do not trample on or roll together, please fold along the center for storage.
- ▲ **The controller is not waterproof, please keep the controller dry to avoid damage during use.**
- ▲ **When it comes to storage, the lamp body can be folded at most twice.**

Name of Parts

Light Body




1. Supporting Holes
2. Light Beads
3. Connection Cable




1. Power Switch Button
2. MODE Button
3. PRESET Button
4. MENU Button
5. SET Select Dial
6. Display
7. DMX OUT Port
8. DMX IN Port
9. DC OUTPUT Port
10. Controller Fixing Device Holder
11. Yellow Battery Remove Button
12. V-mount
13. V-mount Battery Holder
14. Type-A port
15. Black Battery Remove Button
16. DC INPUT Port
17. AC INPUT Port


Controller




Mount the LED Light on the Light Stand




1. Stretch the metal bracket into a square shape.



2. There are two bracket grips in total. Pull out the silver part and insert it into the other grip sleeve, then tighten the screw bolt by hand.




3. Snap one end of the installed bracket grip into the center joint of the square frame, and snap the other end in the same way. Then tighten the screw bolts at both ends by hand, and the metal frame is done.




4. Use the cable tie to fix the light body on the metal frame, then insert the bracket sleeve into the tripod, followed by tightening the fixing knob to complete the installation.


Storage of the Metal Frame



1. Loosen the screw bolts at both ends of the bracket grip, and then remove the bracket grip from the centre of the frame.




2. Fold the middle joint of the frame inward.



3. Lift the metal frame on the right by hand and fold it to the left.


Install the Softbox



Since softbox, grid and diffuser all have velcros, stick the softbox to the LED light along the sides first, then stick the diffuser and grid in order.

Connect to DMX Controller

The connection operation diagram of DMX controller is as follows:




DMX512 controller

Note: DMX connection cable is sold separately.

Multiple connections

What's Inside




Flexible LED Light*1



Controller*1



Metal Bracket*1



Softbox *1



Carry Bag*1



Connection Cable*1



Power Cable*1



Instruction Manual*1



Carry Bag CB88*1

Note: Due to continuous updates and upgrades of the products, there may be differences between the actual products and the pictures. Therefore, the pictures are for reference only, products to prevail in kind.

Separately Sold Accessories



2.4GHz Remote Control RC-A6II




Wireless DMX Transmitter Timlink TX



Wireless DMX Receiver Timlink RX



Controller Fixing Device




Pancake Lantern FP600



DC Cable F-DC5C

Power Supply


1.AC Power Supply



Note : Please press the latch button when disassembling the power cable and connection cable.

2.V-mount battery power supply


Note : The light can be supplied by 14.8v or 26V v-mount battery . Only the side with yellow battery removal button supports one-sided charging . When it is powered by two batteries and one battery is running low on power , the device still can't work normally even if the other one is fully charged . The corresponding battery icon will blink in low battery mode . It is recommended to check whether both batteries have sufficient power when using two batteries.



Power Switch

Long press the power switch button on the controller after connecting to power source to turn the unit on or off.

Short pressing the power switch button in the power on state can reduce the brightness to 0%, short press again to restore the previous brightness.




CCT Mode

Short press the $\text{lock} \rightarrow \text{MODE}$ button to switch to CCT mode, short press the select dial to toggle between brightness setting and CCT setting.

1.In the brightness setting interface, turn the select dial to adjust the brightness ratio from 0% to 100%.Turning the select dial clockwise once will increase the value by 0.1 unit, while turning it counterclockwise will decrease the value by 0.1 unit. Quick adjustment is also available by turning the select dial quickly.


2.In the color temperature setting interface, turn the select dial to adjust the color temperature from 2700K to 8500K. Turning the select dial clockwise once will increase the value by 100 units, while turning it counterclockwise once will decrease the value by 100 units.



FX Mode

Short press the >/MODE button to switch to FX mode, turn the select dial to switch among the following 11 effects: flash, lightning, cloudy, broken bulb, TV, candle, fire, firework, explosion, welding, SOS.

Select the desired effect and short press the select dial to enter the effect setting interface, then short press the >/MODE button to return to previous interface.



1. Flash Effect

In the flash effect setting interface, turn the select dial to select options among switch, dim, auto, manual, CCT, speed, mode, etc. Short press the select dial to select the desired option then rotate to adjust settings (except for the auto and manual options).


DIM: 0%-100%

CCT: 2700K-8500K

Speed: 1-100

Mode: Camera Flash/Flash Bulb

Note: Select manual, then the flash effect can be triggered once by short press the select dial once.



2. Lightning Effect

In the lightning effect setting interface, turn the select dial to select options among switch, dim, auto, manual, CCT, times, frequency, etc. Short press the select dial to select the desired option then rotate to adjust settings (except for the auto and manual options).


DIM: 0%-100%

CCT: 2700K-8500K

Times: Random/1-10

Frequency: Random /2-20

Note: Select manual, then the lightning effect can be triggered once by short press the select dial once.




3. Cloudy Effect

In the cloudy effect setting interface, turn the select dial to select options among switch, dim, ratio, speed, etc. Short press the select dial to select the desired option then rotate to adjust settings.

DIM: 0%-100%

Ratio: 30%-90%

Speed: Random/1-100




4. Broken Bulb Effect

In the broken bulb effect setting interface, turn the select dial to select options among switch, dim, speed, CCT, etc. Short press the select dial to select the desired option then rotate to adjust settings.

DIM: 0%-100%

Speed: 1-100

CCT: 2700K-8500K




5. TV Effect

In the TV effect setting interface, turn the select dial to select options among switch, dim, speed, etc. Short press the select dial to select the desired option then rotate to adjust settings.

DIM: 0%-100%

Speed: 1-100




6. Candle Effect

In the candle effect setting interface, turn the select dial to select options among switch, dim, speed, etc. Short press the select dial to select the desired option then rotate to adjust settings.

DIM: 0%-100%

Speed: 1-100




7. Fire Effect

In the fire effect setting interface, turn the select dial to select options among switch, dim, speed, etc. Short press the select dial to select the desired option then rotate to adjust settings.

DIM: 0%-100%

Speed: 1-100




8. Firework Effect

In the firework effect setting interface, turn the select dial to select options among switch, dim, speed, embers, etc. Short press the select dial to select the desired option then rotate to adjust settings.

DIM: 0%-100%

Speed: 1-100

Embers: 1-100



9. Explosion Effect

In the explosion effect setting interface, turn the select dial to select options among switch, dim, auto, manual, CCT, speed, embers, etc. Short press the select dial to select the desired option then rotate to adjust settings (except for the auto and manual options).


DIM: 0%-100%

CCT: 2700K-8500K

Speed: 1-100

Embers: 1-100

Note: Select manual, then the explosion effect can be triggered once by short press the select dial once.




10. Welding Effect

In the welding effect setting interface, turn the select dial to select options among switch, dim, speed, CCT, etc. Short press the select dial to select the desired option then rotate to adjust settings.

DIM: 0%-100%

Speed: 1-100

CCT: 2700K-8500K




11. SOS Effect

In the SOS effect setting interface, turn the select dial to select options among switch, dim, CCT, etc. Short press the select dial to select the desired option then rotate to adjust settings.

DIM: 0%-100%


CCT: 2700K-8500K

Note: The dimming curve is linear by default in FX mode.




Menu Settings

Short press the MENU button to enter menu settings, turn the select dial to select among the following options: DMX, Bluetooth, wireless, dimming curves, quick boot, display, language, upgrade, factory default, fixture info.



1. DMX

Short press the select dial to enter DMX setting interface. Turn the select dial to select options among address, DMX mode, extend DMX, DMX lost, RDM state. Short press the select dial to select the desired option then rotate to adjust settings. Finally, short press the MENU button to return to the previous menu.



Level 1 Option	Level 2 Option	Description
Address	1-512	Initial address
DMX Mode	1: CCT 8 bit	CCT 8 bit
	2: FX 8 bit	FX 8 bit
	3: ULTIMATE 8 bit	ULTIMATE 8 bit
	4: CCT 16 bit	CCT 16 bit
	5: FX 16 bit	FX 16 bit
	6: ULTIMATE 16 bit	ULTIMATE 16 bit
Extend DMX	On	Turn on extend DMX channels
	Off	Turn off extend DMX channels
DMX Lost	Hold Last Command	After the DMX control signal is lost, continue to use the last received DMX control signal until power down or a valid DMX control signal is received again.
	Black Out	The light is off immediately.
	Black Out After 2 Min	After the DMX control signal is lost, continue to use the last received DMX control signal for 2 minutes then black out. Note: If a valid DMX control signal is received within 2 minutes, then use the new DMX control signal.
RDM Status	On	Turn on RDM
	Off	Turn off RDM

DMX Practical Table

CCT 8Bit Mode						
DMX Channel	Function	Parameters	DMX Value 8 Bit		Practical Parameters Values 8Bit	
			Initial Value	Ending Value	Initial Value	Ending Value
1	CCT	DIM	0	255	0.0%	100.0%
2		CCT	0	255	2700K	8500K

FX 8Bit Mode							
DMX Channel	Function	Parameters	DMX Value 8 Bit		Practical Parameters Values 8Bit		
1	2	FX Type	DIM	0	255	0.0%	100.0%
			0	9	Off		
			10	19	Flash		
			20	29	Lightning		
			30	39	Cloudy		
			40	49	Broken Bulb		
			50	59	TV		
			60	69	Candle		
			70	79	Fire		
			80	89	Firework		
			90	99	Explosion		
			100	109	Welding		
			110	119	SOS		
			120	255	Preset		
3	Flash	CCT	0	255	2700K	8500K	
4		Speed	0	255	1	100	
5		Mode	0	255	0 Camera Flash	1 Flash Bulb	
3	Lightning	CCT	0	255	2700K	8500K	
4		Times	0	255	0(random)	10	
5		Frequency	0	255	0(random)	20	
3	Cloudy	DIM Ratio	0	255	30%	90%	
4		Speed	0	255	0(random)	100	
3	Broken Bulb	CCT	0	255	2700K	8500K	
4		Speed	0	255	1	100	
3	TV	Speed	0	255	1	100	
3	Candle	Speed	0	255	1	100	
3	Fire	Speed	0	255	1	100	
3	Firework	Speed	0	255	1	100	
4		Embers	0	255	1	100	
3	Explosion	CCT	0	255	2700K	8500K	
4		Speed	0	255	1	100	
5		Embers	0	255	1	100	
3	Welding	CCT	0	255	2700K	8500K	
4		Speed	0	255	1	100	
3	SOS	CCT	0	255	2700K	8500K	

ULTIMATE 8Bit Mode						
DMX Channel	Function	Parameters	DMX Value 8 Bit		Practical Parameters Values 8Bit	
1		DIM	0	255	0.0%	100.0%
2		Mode Selection	0	9	CCT Mode	
			10	19	FX Mode	
		20	255	Preset		
3		Color Parameter 1				

CCT Parameter in ULTIMATE 8Bit Mode						
DMX Channel	Function	Parameters	DMX Value 8 Bit		Practical Parameters Values 8Bit	
3	CCT	CCT	0	255	2700K	8500K

FX Parameter in ULTIMATE 8Bit Mode					
DMX Channel	Function	Parameters	DMX Value 8 Bit		Practical Parameters Values 8Bit
3	FX	FX Type	0	9	Off
			10	19	Flash
			20	29	Lightning
			30	39	Cloudy
			40	49	Broken Bulb
			50	59	TV
			60	69	Candle
			70	79	Fire
			80	89	Firework
			90	99	Explosion
			100	109	Welding
			110	119	SOS
			120	255	Preset
4	Flash	CCT	0	255	2700K 8500K
5		Speed	0	255	1 100
6		Mode	0	255	0 Camera Flash 1 Flash Bulb
4	Lightning	CCT	0	255	2700K 8500K
5		Times	0	255	0(random) 10
6		Frequency	0	255	0(random) 20
4	Cloudy	DIM Ratio	0	255	30% 90%
5		Speed	0	255	0(random) 100
4	Broken Bulb	CCT	0	255	2700K 8500K
5		Speed	0	255	1 100
4	TV	Speed	0	255	1 100
4	Candle	Speed	0	255	1 100
4	Firework	Speed	0	255	1 100
5		Embers	0	255	1 100
4	Explosion	CCT	0	255	2700K 8500K
5		Speed	0	255	1 100
6		Embers	0	255	1 100
4	Welding	CCT	0	255	2700K 8500K
5		Speed	0	255	1 100
4	SOS	CCT	0	255	2700K 8500K

CCT 16bit Mode						
DMX Channel	Function	Parameters	DMX value 16 Bit		Practical Parameters Values 16Bit	
			Initial Value	Ending Value	Initial Value	Ending Value
1-2	CCT	DIM	0	65535	0.0%	100.0%
3-4		CCT	0	65535	2700K	8500K

FX 16bit Mode						
DMX Channel	Function	Parameters	DMX value 16 Bit		Practical Parameters Values 16Bit	
1-2		DIM	0	255	0.0%	100.0%
3	FX Type	FX Type	0	9	Off	
			10	19	Flash	
			20	29	Lightning	
			30	39	Cloudy	
			40	49	Broken Bulb	
			50	59	TV	
			60	69	Candle	
			70	79	Fire	
			80	89	Firework	
			90	99	Explosion	
			100	109	Welding	
			110	119	SOS	
			120	255	Preset	
4-5	Flash	CCT	0	255	2700K	8500K
6-7		Speed	0	255	1	100
8-9		Mode	0	255	0 Camera Flash	1 Flash Bulb
4-5	Lightning	CCT	0	255	2700K	8500K
6-7		Times	0	255	0(Random)	10
8-9		Frequency	0	255	0(Random)	20
4-5	Cloudy	DIM Ratio	0	255	30%	90%
6-7		Speed	0	255	0(Random)	100
4-5	Broken Bulb	CCT	0	255	2700K	8500K
6-7		Speed	0	255	1	100
4-5	TV	Speed	0	255	1	100
4-5	Candle	Speed	0	255	1	100
4-5	Fire	Speed	0	255	1	100
4-5	Firework	Speed	0	255	1	100
6-7		Embers	0	255	1	100
4-5		CCT	0	255	2700K	8500K
6-7	Explosion	Speed	0	255	1	100
8-9		Embers	0	255	1	100
4-5	Welding	CCT	0	255	2700K	8500K
6-7		Speed	0	255	1	100
4-5	SOS	CCT	0	255	2700K	8500K

ULTIMATE 16bit						
DMX Channel	Function	Parameters	DMX value 16 Bit		Practical Parameters Values 16Bit	
1-2		DIM	0	255	0.0%	100.0%
3		Mode Selection	0	9	CCT Mode	
			10	19	FX Mode	
			20	255	Preset	
4-5		Color Parameter 1				

CCT Parameter in Ultimate 16Bit Mode						
DMX Channel	Function	Parameters	DMX value 16 Bit		Practical Parameters Values 16Bit	
4-5	CCT	CCT	0	65535	2700K	8500K

FX Parameter in Ultimate 16Bit Mode					
DMX Channel	Function	Parameters	DMX value 16 Bit		Practical Parameters Values 16Bit
4	FX Type	FX Type	0	9	Off
			10	19	Flash
			20	29	Lightning
			30	39	Cloudy
			40	49	Broken Bulb
			50	59	TV
			60	69	Candle
			70	79	Fire
			80	89	Firework
			90	99	Explosion
			100	109	Welding
			110	119	SOS
		120	255	Presets	
5-6	Flash	CCT	0	255	2700K 8500K
7-8		Speed	0	255	1 100
9-10		Mode	0	255	0 Camera Flash 1 Flash Bulb
5-6	Lightning	CCT	0	255	2700K 8500K
7-8		Times	0	255	0 (Random) 10
9-10		Frequency	0	255	0 (Random) 20
5-6	Cloudy	DIM Ratio	0	255	30% 90%
7-8		Speed	0	255	0 (Random) 100
5-6	Broken Bulb	CCT	0	255	2700K 8500K
7-8		Speed	0	255	1 100
5-6	TV	Speed	0	255	1 100
5-6	Candle	Speed	0	255	1 100
5-6	Fire	Speed	0	255	1 100
5-6	Firework	Speed	0	255	1 100
7-8		Embers	0	255	1 100
5-6		Explosion	CCT	0	255
7-8	Speed		0	255	1 100
9-10	Embers		0	255	1 100
5-6	Welding	CCT	0	255	2700K 8500K
7-8		Speed	0	255	1 100
5-6	SOS	CCT	0	255	2700K 8500K

2. Bluetooth


Short press the select dial to enter Bluetooth setting interface. Turn the select dial to select options between switch and reset. Short press the select dial to select the desired option then rotate to adjust settings. Finally, short press the MENU button to return to the previous menu.

Bluetooth MAC Code is on the left bottom of the display for searching the fixture via Bluetooth.

Scan the QR code to download the "Godox Light" smartphone APP (Available for both Android and iOS systems).

Note:

1. The APP can be used directly on the firstly installed device (smartphone or iPad). When change to other mobile device (smartphone or iPad), the light shall be reset before the normal connection of APP.
2. The APP should be upgraded to version 3.0 or above.



3. Wireless


Short press the select dial to enter wireless setting interface. Turn the select dial to select options among switch, GR, CH, ID. Short press the select dial to select the desired option then rotate to adjust settings. Finally, short press the MENU button to return to the previous menu.

Wireless: Turn on/off 2.4G wireless

GR: 0-9/A-F

CH: 01-32


ID: OFF/01-99



Note: When using the remote control RC-A6II (sold separately) or remote control RC-R9II (sold separately), the group, channel and ID of the remote control and F600Bi should be the same.

4. Dimming Curves


Short press the select dial to enter dimming curves setting interface. Turn the select dial to choose among linear, s-curve, exponential and logarithmic. Finally, short press the select dial/MENU button to return to the previous menu.



5. Quick Boot


Short press the select dial to enter quick boot setting interface. Turn the select dial to turn on or off the quick boot function. Finally, short press the select dial/MENU button to return to the previous menu.

Note: The controller will turn on automatically after connecting to power source and the quick boot function is turned on.



6. Display

Short press the select dial to enter display setting interface. Turn the select dial to adjust display brightness from 20% to 100%. Finally, short press the MENU button to return to the previous menu.




7. Language

Short press the select dial to enter language setting interface. Turn the select dial to select between Chinese and English. Finally, short press the MENU button to return to the previous menu.



8. Upgrade

Short press the select dial to enter upgrade setting interface to check the firmware version and upgrade instruction. Then, short press the MENU button to return to the previous menu.



Firmware Upgrade


1. Download the new firmware to the U disk from official website <https://www.godox.com/firmware-continuous-light>.
2. Turn off the device. Insert the U disk with new firmware into the Type-A USB port.
3. Turn on the device, and it will automatically enter the upgrading interface.
4. It will return to main interface after completion.

Notes:

1. New firmware must be downloaded from the official website, and keep only one BIN file in the root directory of the USB disk.
2. The Type-A USB port can only support output voltage and current of 5V/1A. Do not connect to over-rated USB device.


9. Factory Default

Short press the select dial to enter factory default setting interface. Turn the select dial to select apply or cancel. It will return to language setting interface after reset.





10. Fixture Info


Short press the select dial to enter fixture info setting interface to check model, UID NO. and firmware version. Then, short press the MENU button to return to the previous menu.



Lock Setting

Short press the  /MODE button, the panel is locked when  is displayed on the panel, short press again to unlock.


Note: The locking function only works on the controller panel, other operations are still available.



Preset Setting

Short press the PRESET button to enter preset effects interface. Turn the select dial to choose and enter preset effects 1-10, then short press to choose save or cancel. Then, short press the select dial to return to the previous menu and short press the PRESET button to exit.

Note: It will not display any option for certain group that have not been preset any effect.



Maintenance

This product, except consumables, is supported with a one-year warranty. Unauthorized service will void the warranty. Maintenance of the light must be performed by our authorized maintenance department which can provide original accessories. Changes made to the specifications or designs may not be reflected in this manual.

Illuminance Data

CCT	Unit	1m	2m	3m	5m
2700K	lux	≈16300	≈5640	≈2670	≈1060
	fc	≈1510	≈524	≈248	≈98.9
3200K	lux	≈17400	≈6020	≈2860	≈1130
	fc	≈1620	≈559	≈265	≈105
4300K	lux	≈19200	≈6620	≈3130	≈1240
	fc	≈1790	≈615	≈291	≈115
5600K	lux	≈19900	≈6830	≈3240	≈1280
	fc	≈1850	≈635	≈301	≈119
6500K	lux	≈19700	≈6740	≈3200	≈1270
	fc	≈1830	≈626	≈297	≈118
8500K	lux	≈18800	≈6440	≈3050	≈1210
	fc	≈1750	≈598	≈283	≈113

The data above are averages, not absolutes. All the above tests are based on the condition of 100% brightness.

Technical Data

Model	F600Bi
Power Supply	100V-240V~50/60Hz 6.7A
Input Power	≈670W
CCT	2700-8500K
Brightness Range	0%-100%
Dimming Curves	linear, s-curve, exponential, logarithmic
FX Modes	11
CRI	Average ≥96
TLCI	Average ≥96
Waterproof Rating of Light Body	IP65
Controlling Methods	DMX 512 Control (support RDM protocol) / 2.4GHz Wireless Control/ Bluetooth APP Control
Bluetooth Controlling Distance	≈30m
2.4G Remote Control Distance	≈60m
Type-A USB Port	Firmware Upgrade/5V=1A Power Supply
Dimension	Light Body: 1210mm*1210mm*24mm (excluding DC cable) Controller: 179mm*123mm*332mm
Netweight*	Light Body: 3.8Kg Controller: 3.9Kg

Specifications and data may subject to changes without notice.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

Warning

Operating frequency:2412.99MHz – 2464.49MHz(2.4G only receive)/2402MHz – 2480MHz (BT)
Maximum EIRP Power: 5dBm

Declaration of Conformity

GODOX Photo Equipment Co.,Ltd. hereby declares that this equipment are in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. In accordance with Article 10(2) and Article 10(10), this product is allowed to be used in all EU member states. For more information of DoC, Please click this web link:

<https://www.godox.com/eu-declaration-of-conformity/>

The device complies with RF specifications when the device used at 0mm from your body.

产品保修

尊敬的用户, 本保修卡是申请保修服务的重要凭证, 请您配合销售商填写并妥善保管, 谢谢!

产品信息	型号	产品条码
用户信息	姓名	联系电话
	通信地址	
销售商信息	名称	
	联系电话	
	通信地址	
	销售日期	
备注		

注: 此表应由销售商盖章确认。

产品信息

本文件适用于相关《产品保修信息》(见后面说明)所列产品, 其他非属此范围的产品或部件(如促销品、赠品及其他出厂后附加的部件等)不在此保修承诺内。

保修期

产品及部件的相应保修期按相关的《产品保修信息》执行。保修期自产品首次购买日起算, 购买日以下购买产品时保修卡登记日期为准。

如何获得保修服务

您可直接与产品销售商或授权服务机构联系, 也可拨打神牛产品售后服务电话, 与我们联系, 由我们的服务人员为您安排服务。申请保修时, 您应提供有效的保修卡作为保修凭证, 方可获得保修。如您不能提供有效的保修卡, 则在我们确认产品或部件属于保修范围的情况下, 也可以为您提供保修, 但这不作为我们的义务。

不适用保修的情况

如产品存在下列情况，本文件项下的保证和服务将不适用：①产品或部件超过相应保修期；②错误或不适当使用、维护或保管导致的故障或损坏，如：不当搬运；非按产品合理预期用途使用；不当插拔外接设备；跌落或外力挤压；接触或暴露于不当温度、溶剂、酸碱、水浸或潮湿环境；③由非神牛授权机构或人员安装、修理、更改、添加或拆卸造成的故障或损坏；④产品或部件原有识别信息被修改变更或删除；⑤无有效保修卡；⑥使用非法授权、非标准或非公开发行的软件造成的故障或损坏；⑦因不可抗力或意外事件造成的故障或损坏；⑧其他非因产品本身质量问题导致的故障或损坏。遇上述情况，您应向相关责任方寻求解决，神牛对此不承担任何责任。因非在保修期或保修范围内的部件、附件或软件导致产品不能正常使用的，不是保修范围内的故障。产品使用过程中正常的脱色，磨损和消耗，不是保修范围内的故障。

产品保修和服务支持信息

产品的保修期和服务类型按以下《产品保修信息》执行：

产品类别	选件名称	保修期(月)	保修服务类型
部件	主机	12	客户送修
	电池	3	客户送修
	充电器等带电性能的部件。	12	客户送修
其他	如电源线、同步线、外壳、保护罩、锁紧装置、包装等。	无	无保修

神牛产品售后服务电话 0755-29609320-8062

Warranty

Dear customers, as this warranty card is an important certificate to apply for our maintenance service, please fill in the following form in coordination with the seller and safe-keep it. Thank you!

Product Information	Model	Product Code Number
Customer Information	Name	Contact Number
	Address	
Seller Information	Name	
	Contact Number	
	Address	
	Date of Sale	
Note		

Note: This form shall be sealed by the seller.

Applicable Products

The document applies to the products listed on the Product Maintenance Information (see below for further information). Other products or accessories (e.g. promotional items, giveaways and additional accessories attached, etc.) are not included in this warranty scope.

Warranty Period

The warranty period of products and accessories is implemented according to the relevant Product Maintenance Information. The warranty period is calculated from the day (purchase date) when the product is bought for the first time. And the purchase date is considered as the date registered on the warranty card when buying the product.

How to Get the Maintenance Service

If maintenance service is needed, you can directly contact the product distributor or authorized service institutions. You can also contact the Godox after-sale service call and we will offer you service. When applying for maintenance service, you should provide valid warranty card. If you cannot provide valid warranty card, we may offer you maintenance service once confirmed that the product or accessory is involved in the maintenance scope, but that shall not be considered as our obligation.

Inapplicable Cases

The guarantee and service offered by this document are not applicable in the following cases: ① The product or accessory has expired its warranty period; ② Breakage or damage caused by inappropriate usage, maintenance or preservation, such as improper packing, improper usage, improper plugging in/out external equipment, falling off or squeezing by external force, contacting or exposing to the improper temperature, solvent, acid, base, flooding and damp environments, etc; ③ Breakage or damage caused by non-authorized institution or staff in the process of installation, maintenance, alternation, addition and detachment; ④ The original identifying information of product or accessory is modified, alternated, or removed; ⑤ No valid warranty card; ⑥ Breakage or damage caused by using

illegally authorized, nonstandard or non-public released software; ⑦ Breakage or damage caused by force majeure or accident; ⑧ Breakage or damage that could not be attributed to the product itself. Once met these situations above, you should seek solutions from the related responsible parties and Godox assumes no responsibility. The damage caused by parts, accessories and software that beyond the warranty period or scope is not included in our maintenance scope. The normal discoloration, abrasion and consumption are not the breakage within the maintenance scope.

Maintenance and Service Support Information

The warranty period and service types of products are implemented according to the following Product Maintenance Information:

Product Type	Name	Maintenance Period(month)	Warranty Service Type
Parts	Circuit board	12	Customer sends the product to designated site
	Battery	3	Customer sends the product to designated site
	Electrical parts e.g.battery charger, etc.	12	Customer sends the product to designated site
Other Items	Power cord, sync cable, lamp body, lamp cover,lockingdevice, package, etc.	No	Without warranty

Godox After-sale Service Call +86-755-29609320(8062)